



SOSS OFFERS A ROUTER GUIDE SYSTEM WHERE ONE SETUP PROVIDES FAST ACCURATE MORTISING ON BOTH DOOR AND FRAME. SEE CHART FOR ROUTER GUIDE PART NUMBERS FOR EACH SIZE HINGE.

SEE CATALOG NOMOGRAPH TO DETERMINE THE NUMBER OF HINGES REQUIRED FOR A DOOR OF KNOWN WEIGHT AND HEIGHT.

LOCATION IS NOT CRITICAL ON DOORS REQUIRING MORE THAN 7 HINGES. LOCATE MOST HINGES IN THE TOP HALF OF THE DOOR.

DO NOT SCALE DRAWING

ROUTER GUIDE SYSTEMS	
#216 - PART#	216RG4
#218 - PART#	218RG4
#220 - PART#	220RG4
#416 - PART#	416RG4
#418 - PART#	418RG4

UIP ©Copyright
 Universal Industrial Products, Inc.
 One Coreway Drive
 Pioneer, Ohio 43554-0628

SCALE: NONE

DRAWN BY: NNM

SOSS INVISIBLE HINGE

DATE: 5/01/11

VERTICAL HINGE LOCATION ON DOOR

DRAWING #4440-C